

## BEST PRACTICE GUIDE

# USING YOUR UCLEAR

## Bluetooth Communication System

### Preparing the Communication Systems for Groups



**1** Turn on all units you wish to group by pressing the power button. Once turned on, allow around 10 seconds for each unit to complete its power on sequence. Once finished, the indicator light on all units should single blink blue.



**2** Select any unit from the group and press the up arrow for 5 seconds. Release when the unit's LED indicator blinks fast purple/white momentarily. If you are wearing the hard hat, you will hear a single beep when performing this function. This indicates that intercom has been activated. You will now wait until all units have self-activated. (For larger groups, you will notice each unit follow the same quick purple/white flashing sequence as the network enables all the units for intercom mode.) Once this is complete, the indicator light on all units in the group will double blink blue. The entire process will take a total of around 30 seconds or so.



**3** To complete the process, a single (touch and release) press of the power button on each unit will activate the microphones for that unit. Microphones on single units can be muted and unmuted at any time with a quick press of the power button.

### Operating the Communication Systems

#### Volume

Participants can adjust their listening volume with a single (touch and release) press of the up or down arrow to increase or decrease volume. It is important that participants not press and hold any buttons as that could disrupt intercom.

#### Restoring Intercom

If anyone leaves the group or breaks line of sight, the communication chain will break. To correct this, identify the group number that left. Using the next number up from the missing unit, press the communication unit's up arrow for 5 seconds to trigger a chain healing process. This will restore the group communication.